

PCG09 | Quick Start Guide





Thanks for Choosing MeLE PCG09!







Products Specification

2

Processor Intel Atom Z3735F (quad-core, 1.33 GHz)
Burst speed up to 1.83 GHz

Graphics Processor Intel HD Graphics

Memory 2GB DDR3L 1333MHz

Storge 32GB eMMC (Support internal 2.5" SATA HDD or M.2 SSD)

USB Ports Three USB 2.0 ports

Networking 10/100Mbps Ethernet

Wireless Networking 802.1 n / 802.1 a(Dual Band)

Bluetooth 4.0

Operating System Windows 8.1 OS



The power LED blinks when the box is powered on.





Connection

Adjusting the resolution of video output via HDMI / VGA to HDTV or Monitor

Follow the steps below to adjust the video output when connection the WinPC to a HDTV or monitor via HDMI/VGA

- 1. Please presse right key of mouse and choose Graphics Proertis.
- 2. Double click Display.
- 3, Choose the correct "resolution" and "Refresh Rate " to adjust to correct display on TV.



Configuring audio output via an HDMI device or Audio digital devices

Follow the steps below to enable audio output when connection the WinPC to a TV or audio digital devices via HDMI or 3.5mm stere jack.

- 1. Access the Sound settings via the system Control Panel.
- 2. Under Playback devices, click the display device that corresponds with your HDMI audiocompatible display.
- 3. Click the Set Default button in the lower right hand corner.
- 4. Click OK to exit the setup.




HDD installation

Please take below steps for HDD installation, PCG09 Support maximun 2TB 2.5" HDD


- 1. Screw, and take away the upper casing
- 2. Release the two locks of HDD
- 3. put in the HDD
- 4. lock the HDD
- 5. Put back upper casing, and Screw




Step1



Step2



Step3



Step4